



Обозначение головы	Резьба	Артикул
UM01	M3,5x0,6	355092 0102
	M4x0,7	355092 0106
	M4-4,5x0,75	355092 0110
	M5x0,8	355092 0114
	M5-5,5x0,9	355092 0118
	M6x1	355092 0122
UM1	M6-8x1	355092 0206
	M8-9x1,25	355092 0210
	M10x1,5	355092 0214
UM12	-	-

Обозначение головы	Резьба	Артикул
UM2	M8-10x1,25	355092 0402
	M10-12x1,5	355092 0406
	M12-14x1,75	355092 0410
	M14-16x2	355092 0414
UM23	-	-
UM3	M12-14x1,75	355092 0602
	M14-16x2	355092 0606
	M18-20x2,5	355092 0610
	M20-22x2,5	355092 0614
UM34	-	-

Обозначение головы	Резьба	Артикул
UM4	M14-16x2	355092 0802
	M18-20x2,5	355092 0806
	M20-22x2,5	355092 0810
	M24-27x3	355092 0814
	M27-30x3,5	355092 0818
UM233400	-	-
UM5	M18-20x2,5	355092 1002
	M20-22x2,5	355092 1006
	M24-27x3	355092 1010
	M30-33x3,5	355092 1014
	M36-39x4	355092 1018
UM45	-	-
UM56	-	-

## 355 094 Ролики резьбовые для метрической резьбы MF



Обозначение головы	Резьба MF	Артикул	
UM01	M4-5x0,5	355094 0102	
UM1	MF6-8x0,75	355094 0206	
	MF8-10x1	355094 0210	
	MF10-11x1,25	355094 0214	
UM12	MF6-7x0,5	355094 0302	
	MF7-8x0,5	355094 0306	
	MF6-7x0,75	355094 0310	
	MF8-9x0,75	355094 0314	
	MF9-10x0,75	355094 0318	
	MF10-11x0,75	355094 0322	
	MF11-12x0,75	355094 0326	
	MF8-9x1	355094 0330	
	MF9-10x1	355094 0334	
	MF10-11x1	355094 0338	
	MF11-12x1	355094 0342	
	MF10-11x1,25	355094 0346	
	MF11-12x1,25	355094 0350	
	MF12x1,5	355094 0354	
UM2	MF8-10x1	355094 0402	
	MF10-12x1,25	355094 0406	
	MF12-14x1,5	355094 0410	
UM23	MF8-10x0,5	355094 0502	
	MF8-10x0,75	355094 0506	
	MF10-12x0,75	355094 0510	
	MF10-12x1	355094 0514	
	MF12-14x1	355094 0518	
	MF14-16x1	355094 0522	
	MF16-18x1	355094 0526	
	MF18-20x1	355094 0530	
	MF14-16x1,25	355094 0534	
	MF16-18x1,5	355094 0538	
	MF18-20x1,5	355094 0542	
	MF20-22x1,5	355094 0546	
	UM3	MF12-14x1,5	355094 0602
		MF14-16x1,5	355094 0606
		MF18-20x2	355094 0610
MF20-22x2		355094 0614	

Обозначение головы	Резьба MF	Артикул
UM34	MF12-14x1	355094 0702
	MF14-16x1	355094 0706
	MF16-18x1	355094 0710
	MF18-20x1	355094 0714
	MF16-18x1,5	355094 0718
	MF18-20x1,5	355094 0722
	MF20-22x1,5	355094 0726
	MF22-24x1,5	355094 0730
	MF24-27x1,5	355094 0734
	MF27-30x1,5	355094 0738
UM4	MF14-16x1,5	355094 0802
	MF16-18x1,5	355094 0806
	MF18-20x2	355094 0810
	MF22-24x2	355094 0814
UM233400	MF16-18x1,5	355094 0902
	MF18-20x1,5	355094 0906
	MF20-22x1,5	355094 0910
	MF22-24x1,5	355094 0914
	MF24-26x1,5	355094 0918
	MF26-28x1,5	355094 0922
	MF28-30x1,5	355094 0926
	MF30-32x1,5	355094 0930
	MF32-34x1,5	355094 0934
	MF34-36x1,5	355094 0938
	MF22-24x2	355094 0942
	MF24-26x2	355094 0946
	MF26-28x2	355094 0950
	MF28-30x2	355094 0954
	MF30-32x2	355094 0958
MF32-34x2	355094 0962	
MF34-36x2	355094 0966	
UM5	MF18x1,5	355094 1002
	MF18-20x2	355094 1006
	MF20-22x2	355094 1010
	MF22-24x2	355094 1014
	MF30-33x3	355094 1018
	MF33-36x3	355094 1022

Обозначение головы	Резьба MF	Артикул
UM45	MF16-18x1	355094 1102
	MF18-20x1	355094 1106
	MF20-22x1	355094 1110
	MF22-24x1	355094 1114
	MF18-20x1,5	355094 1118
	MF20-22x1,5	355094 1122
	MF22-24x1,5	355094 1126
	MF24-27x1,5	355094 1130
	MF27-30x1,5	355094 1134
	MF30-33x1,5	355094 1138
	MF33-36x1,5	355094 1142
	MF36-39x1,5	355094 1146
	MF38-40x1,5	355094 1150
	MF24-27x2	355094 1154
	MF27-30x2	355094 1158
UM56	MF30-33x2	355094 1162
	MF33-36x2	355094 1166
	MF36-39x2	355094 1170
	MF39-42x2	355094 1174
	MF22-24x1,5	355094 1202
	MF24-27x1,5	355094 1206
	MF27-30x1,5	355094 1210
	MF30-33x1,5	355094 1214
	MF33-36x1,5	355094 1218
	MF36-39x1,5	355094 1222
	MF39-42x1,5	355094 1226
	MF42-45x1,5	355094 1230
	MF45-48x1,5	355094 1234
	MF27-30x2	355094 1238
	MF30-33x2	355094 1242
MF33-36x2	355094 1246	
MF36-39x2	355094 1250	
MF39-42x2	355094 1254	
MF42-45x2	355094 1258	
MF45-48x2	355094 1262	
MF48-50x2	355094 1266	
MF50-52x2	355094 1270	
MF42-45x3	355094 1274	
MF45-48x3	355094 1278	
MF48-50x3	355094 1282	
MF50-52x3	355094 1286	